



NOTES:

Airlift improves treatment quality through constant flow to ATU. This method is recommended for sites with high surges, such as restaurants, and is not necessary for typical residential applications.

This flow equalizing method does not replace the requirement for timed dosing to the disposal unit after the ATU.

Adjust ball valve to control outlet flow rate from airlift to 0.5 gpm at full tank depth.

At minimum liquid level, flow will stop.



PRE-TRASH TANK DETAIL WITH FLOW-EQUALIZING AIRLIFT

ENVIRO-FLO, INC.
Wastewater Treatment Technologies
P.O. BOX 321161, Flowood, MS 39232
(877) 836-8476 (601) 845-4716 fax
www.enviro-flo.net

DATE: **5/02/11**