



PARTS LIST

NuWater NR Assembly Diagram

- A. DUAL PORT AERATOR
- B. 3/8" RUBBER 90° W/ CLAMPS (2)
- C. 3/8" BARBED ADAPTOR X 1/2" NPT (2)
- D. 1/2" SLIP X 1/2" NPT ADAPTOR
- E. 1" STREET X 1/2" NPT BUSHING (3)
- F. 1/2" 90° ELBOW (3)
- G. 1" X 1" X 1/2" TEE
- H. 1" 90° ELBOW (3)
- I. 2" X 1" BUSHING
- J. 2" SANITARY TEE
- K. 1" PVC CROSS
- L. 1" COUPLER (BY INSTALLER)
- M. POLY DIFFUSER BAR (2)
- N. 1" PVC (3 1/2" SECTION)
- O. 1" SLIP CAP
- P. 1/8" CLEAR PVC HOSE (OPTIONAL 5')
- Q. 1/2" PVC PIPE (BY INSTALLER)
- R. 1" PVC PIPE (BY INSTALLER)
- S. 2" PVC PIPE (BY INSTALLER)
- T. 1/8" BARBED ADAPTOR TO 1/4" NPT (2)
- U. 1/2" STREET X 1/4" NPT BUSHING (2)
- V. 1/2" PVC COUPLER (2)
- W. 2" COUPLER (BY INSTALLER)