
Panel Wiring Diagram Model EAS-LAA



Operation: A low air condition activates the alarm light and audible alarm. The audible alarm may be silenced by pressing the illuminated PUSH TO SILENCE button on the bottom of the alarm panel. The alarm light will remain on until the low air condition is corrected.



Key

= Factory Wire
= Field Wire
= Audio Alarm, 115 VAC

AL = Alarm Light AS = Air Switch

SI = Silence Switch SR = Silence Control Relay (2P)